



# CS 423

## Operating System Design

### Synchronization (II)

Ramnatthan Alagappan  
Tianyin Xu

\* Thanks for Prof. Adam Bates for the slides.

# Implementing Synchronization



- Take 1: using memory load/store
  - See too much milk solution/Peterson's algorithm
- Take 2: *(corrected from last class!)*

```
Lock::acquire() {  
    disableInterrupts();  
}
```

```
Lock::release() {  
    enableInterrupts();  
}
```

Above solution “works” on single processor...

# Let's write some simple code



Let's write a smarter implementation of acquire/release

- The key idea is to enable interrupts back ASAP

```
Lock::acquire() {  
    disableInterrupts();
```

```
Lock::release() {  
    disableInterrupts();
```

```
;
```

```
    enableInterrupts();
```

```
}
```

```
    enableInterrupts();
```

```
}
```

# Let's write some simple code



Let's write a smarter implementation of acquire/release

- The key idea is to enable interrupts back ASAP
- Use queues – ready queue and wait queue

```
Lock::acquire() {  
    disableInterrupts();
```

```
Lock::release() {  
    disableInterrupts();
```

```
    enableInterrupts();  
}
```

```
    enableInterrupts();  
}
```

# Let's write some simple code



- Let's use two queues: a read queue and a wait queue
- You can use `queue.add()/remove()`
- Please use 7.5 minutes to write the acquire and release

```
Lock::acquire() {  
    disableInterrupts();
```

```
Lock::release() {  
    disableInterrupts();
```

```
    enableInterrupts();
```

```
    enableInterrupts();
```

```
}
```

```
}
```

# Queueing Lock Implementation (1 Proc)



```
Lock::acquire() {
    disableInterrupts();
    if (value == BUSY) {
        waiting.add(myTCB);
        myTCB->state = WAITING;
        next = readyList.remove();
        switch(myTCB, next);
        myTCB->state = RUNNING;
    } else {
        value = BUSY;
    }
    enableInterrupts();
}
```

```
Lock::release() {
    disableInterrupts();
    if (!waiting.Empty()) {
        next = waiting.remove();
        next->state = READY;
        readyList.add(next);
    } else {
        value = FREE;
    }
    enableInterrupts();
}
```

# Question



**Why won't this work for multiprocessing?**

# Multiprocessor Sync Tool!



- **Read-modify-write (RMW) instructions**
  - Atomically read a value from memory, operate on it, and then write it back to memory
  - Intervening instructions prevented in hardware
- **Examples**
  - Test and set
  - Intel: xchgb, lock prefix
  - Compare and swap
- **Any of these can be used for implementing locks and condition variables!**



# Test-and-set



- The **test-and-set** instruction is an instruction used to write 1 (set) to a memory location and return its old value as a single **atomic** (i.e., non-interruptible) operation. If multiple processes may access the same memory location, and if a process is currently performing a test-and-set, no other process may begin another test-and-set until the first process's test-and-set is finished.
- Please implement a lock using test-and-set (5 minutes)

```
lock:acquire() {
```

```
}
```

```
lock:release() {
```

```
}
```

# Spinlocks



- A spinlock is a lock where the processor waits in a loop for the lock to become free
  - Assumes lock will be held for a short time
  - Used to protect the CPU scheduler and to implement locks

```
Spinlock::acquire() {  
    while (testAndSet(&lockValue) == BUSY)  
        ;  
}
```

```
Spinlock::release() {  
    lockValue = FREE;  
    memorybarrier();  
}
```

# Question



**Neat. So how many spinlocks do we need?**

# What thread is currently running?



- Thread scheduler needs to find the TCB of the currently running thread
  - To suspend and switch to a new thread
  - To check if the current thread holds a lock before acquiring or releasing it
- On a uniprocessor, easy: just use a global
- On a multiprocessor, various methods:
  - Compiler dedicates a register (e.g., r31 points to TCB running on the this CPU; each CPU has its own r31)
  - If hardware has a special per-processor register, use it
  - Fixed-size stacks: put a pointer to the TCB at the bottom of its stack



## Lock implementation —

```
Lock::acquire() {
    disableInterrupts();
    spinLock.acquire();
    if (value == BUSY) {
        waiting.add(myTCB);
        scheduler->
            suspend(&spinlock);
    } else {
        value = BUSY;
    }
    spinLock.release();
    enableInterrupts();
}
```

```
Lock::release() {
    TCB *next;

    disableInterrupts();
    spinLock.acquire();
    if (!waiting.Empty()) {
        next = waiting.remove();
        scheduler->makeReady(next);
    } else {
        value = FREE;
    }
    spinLock.release();
    enableInterrupts();
}
```





## Lock implementation (7.5 minutes)

```
Lock::acquire() {
    disableInterrupts();
    spinLock.acquire();
    if (value == BUSY) {
        waiting.add(myTCB);
        scheduler->
            suspend(&spinlock);
    } else {
        value = BUSY;
    }
    spinLock.release();
    enableInterrupts();
}
```

```
Lock::release() {
    TCB *next;

    disableInterrupts();
    spinLock.acquire();
    if (!waiting.Empty()) {
        next = waiting.remove();
        scheduler->makeReady(next);
    } else {
        value = FREE;
    }
    spinLock.release();
    enableInterrupts();
}
```



## Scheduler implementation —

```
Sched::suspend(SpinLock *lock) {
    TCB *next;

    disableInterrupts();
    schedSpinLock.acquire();
    lock->release();
    myTCB->state = WAITING;
    next = readyList.remove();
    thread_switch(myTCB, next);
    myTCB->state = RUNNING;
    schedSpinLock.release();
    enableInterrupts();
}

Sched::makeReady(TCB *thread) {
    disableInterrupts();
    schedSpinLock.acquire();
    readyList.add(thread);
    thread->state = READY;
    schedSpinLock.release();
    enableInterrupts();
}
```



# Locks for user space??



- Kernel-managed threads
  - Manage data structures in kernel space
  - System calls to communicate w/ scheduler
- User-managed threads
  - Implement functionality in thread library
  - Can't disable interrupts, but can temporarily disable upcalls to avoid preemption in library scheduler, etc.

# Spinning vs Context Switch



- **What's the tradeoff?**

# Locks in Linux



- Most locks are free most of the time. Linux implementation takes advantage of this fact!
- Fast path:
  - If lock is FREE, and no one is waiting, two instructions to acquire the lock
  - If no one is waiting, two instructions to release the lock
- Slow path
  - If lock is BUSY or someone is waiting, use multiproc impl.
- User-level locks also optimized:
  - Fast path: count is mapped to proc address space, no sys call needed when count is 0.
  - Slow path: system call to kernel, use kernel lock when waiting

# Locks in Linux



Lock struct contains 3 (not two) states...

```
struct mutex {
    /* 1: unlocked ;
       0: locked;
       negative : locked, possible waiters */
    atomic_t count;
    spinlock_t wait_lock;
    struct list_head wait_list;
};
```

Lock acquire code is a macro (to avoid proc call)...

```
lock decl (%eax)                // atomic decrement
                                // %eax is pointer to count
jns 1f                          // jump if not signed
                                // (i.e., if value is now 0)

call slowpath_acquire
1: ...
```

# Synchronization: Semaphores



- Semaphore has a non-negative integer value
  - P() atomically waits for value to become  $> 0$ , then decrements
  - V() atomically increments value (waking up waiter if needed)
- Semaphores are like integers except:
  - Only operations are P and V
  - Operations are atomic
    - If value is 1, two P's will result in value 0 and one waiter

# Compare Implementations



Lock implementation —

```
Lock::acquire() {
    disableInterrupts();
    spinLock.acquire();
    if (value == BUSY) {
        waiting.add(myTCB);
        suspend(&spinlock);
    } else {
        value = BUSY;
    }
    spinLock.release();
    enableInterrupts();
}
```

```
Lock::release() {
    disableInterrupts();
    spinLock.acquire();
    if (!waiting.Empty()) {
        next = waiting.remove();
        scheduler->makeReady(next);
    } else {
        value = FREE;
    }
    spinLock.release();
    enableInterrupts();
}
```

# Compare Implementations



## Semaphore implementation —

```
Semaphore::P() {
    disableInterrupts();
    spinLock.acquire();
    if (value == 0) {
        waiting.add(myTCB);
        suspend(&spinlock);
    } else {
        value--;
    }
    spinLock.release();
    enableInterrupts();
}
```

```
Semaphore::V() {
    disableInterrupts();
    spinLock.acquire();
    if (!waiting.Empty()) {
        next = waiting.remove();
        scheduler->makeReady(next);
    } else {
        value++;
    }
    spinLock.release();
    enableInterrupts();
}
```

# Semaphores Harmful?



- Semaphores conflate the roles of locks and condition variables (mutual exclusion, shared data).
  - Simpler code verification w/o: *prove every lock is eventually unlocked.*
- Semaphores have state!
  - What does value=3 mean? Programmer must carefully map object state to semaphore value.
  - CVs, in contrast, allows us to wait on arbitrary state/predicate, and are thus a better abstraction.
- However, semaphores have good uses, including...
  - Unlocked waits, e.g., interrupt handler that synchronizes communication between I/O device and waiting threads.



# Semaphore Bounded Queue



```
get() {
    fullSlots.P();
    mutex.P();
    item = buf[front % MAX];
    front++;
    mutex.V();
    emptySlots.V();
    return item;
}
```

```
put(item) {
    emptySlots.P();
    mutex.P();
    buf[last % MAX] = item;
    last++;
    mutex.V();
    fullSlots.V();
}
```

Initially: front = last = 0; MAX is buffer capacity  
mutex = 1; emptySlots = MAX; fullSlots = 0;



How can we implement Condition Variables using semaphores

## Take 1:

```
wait(lock) {
    lock.release();
    semaphore.P();
    lock.acquire();
}
signal() {
    semaphore.V();
}
```

Problems?



How can we implement Condition Variables using semaphores

## Take 2:

```
wait(lock) {
    lock.release();
    semaphore.P();
    lock.acquire();
}
signal() {
    if (semaphore is not empty)
        semaphore.V();
}
```

Problems?

# Implementing CVs w/ Semaphores



How can we implement Condition Variables using semaphores

## Take 3:

```
wait(lock) {
    semaphore = new Semaphore;
    queue.Append(semaphore);    // queue of waiting threads
    lock.release();
    semaphore.P();
    lock.acquire();
}
signal() {
    if (!queue.Empty()) {
        semaphore = queue.Remove();
        semaphore.V();    // wake up waiter
    }
}
```

Problems?

# Implementing CVs w/ Semaphores



Implementation used for Microsoft Windows before native support was offered:

## Take 4:

```
//Put thread on queue of waiting threads...
```

```
void CV::wait(Lock *lock){  
    semaphore = new Semaphore(0);  
    waitQueue.Append(semaphore)  
    lock.release();  
    semaphore.P();  
    lock.acquire();  
}
```

```
//Wake up one waiter if any.
```

```
void CV::signal() {  
    if(!waitQueue.isEmpty()) {  
        semaphore = queue.Remove();  
        semaphore.V();  
    }  
}
```